ENGINEERING
TOMORROW

Installation guide

ESMR / 087B1057

ESMR - Pt 1000 room sensor




①

Use screwdriver to open the case.

DK: Brug en skruetrækker til at åbne kabinettet.

DE: Verwenden Sie einen Schraubendreher, um das Gehäuse zu öffnen.




②

Connect wires to pins.

DK: Forbind ledningerne til stifterne.

DE: Verbinde die Drähte mit den Pins.




TEMPERATURE Pt1000

③

Feed cable thorough the inlet in the center of backplate or thorough one of the corner holes.

DK: Før kablet gennem indgangen i midten af bagpladen eller gennem et af hjørnehullerne.

DE: Führen Sie das Kabel durch die Öffnung in der Mitte der Rückplatte oder durch eines der Ecklöcher.



© Danfoss | 2026.05


ESMR

④

Mount on the wall with screws (not included).

DK: Monteres på væggen med skruer (medfølger ikke).

DE:Mit Schrauben an der Wand befestigen (Schrauben nicht im Lieferumfang enthalten).




⑤

Dimensions

DK: Dimensioner

DE: Abmessungen



ESMR: www.danfoss.com

https://www.youtube.com/DanfossClimate
-> Playlists -> How-to Videos -> District Energy installation videos

Danfoss A/S
Climate Solutions • danfoss.com • +45 7488 2222

Any information, including, but not limited to information on selection of product, its application or use, product design, weight, dimensions, capacity or any other technical data in product manuals, catalogues descriptions, advertisements, etc. and whether made available in writing, orally, electronically, online or via download, shall be considered informative, and is only binding if and to the extent, explicit reference is made in a quotation or order confirmation. Danfoss cannot accept any responsibility for possible errors in catalogues, brochures, videos and other material.
Danfoss reserves the right to alter its products without notice. This also applies to products ordered but not delivered provided that such alterations can be made without changes to form, fit or function of the product.
All trademarks in this material are property of Danfoss A/S or Danfoss group companies. Danfoss and the Danfoss logo are trademarks of Danfoss A/S. All rights reserved.