

Smile Connect Installation Kit SCI-10

PRODUCT DATA

GENERAL

The Smile Connect installation kit is used to perform the initial setup of a SCN-10.

The installation is carried out directly with a PC.

After connecting the PC using the SCI-10 Adapter, the device can be set up independent of the customer's Wifi network.

The system can thus be operated without using the customer's Wifi network.

FEATURES

- **USB-to-Ethernet converter**

APPLICATION

- **The Ethernet RJ45 connector is plugged into the PC and the USB connector is plugged into the SCN-10. After starting the browser on the PC, the installation wizard starts and the installer can do the initial setup of the system.**

SYSTEM REQUIREMENTS

Ports	USB2.0
Operating system	Windows XP or higher Apple MAC OS
Browser	Mozilla Firefox, Apple Safari, Google Chrome

TECHNICAL DATA

Connectors	USB and Ethernet RJ45
Cable length	15 cm (incl. USB connector)
Storage temperature	-25 ... +60 °C
Operating temperature	-10 ... +50 °C
Dimensions	65*22*15mm (LxWxH)
Weight	20 g
EAN Code	4046911076198
EMC 2004/108/EC	EN 61000-3-2:2006 + A1:2009 + A2:2009; EN 61000-3-3-2013
Low voltage directive 2006/95/EG	EN 55022:2010 EN 55024:2010
ROHS 2011/65/EU	Conform

Honeywell

Manufactured for and on behalf of the Environmental & Energy Solutions Division of Honeywell Technologies Sàrl, Rolle, Z.A. La Pièce 16, Switzerland by its Authorized Representative:

Automation and Control SolutionsHoneywell GmbH
Böblinger Strasse 17
71101 Schönaich, Germany
Phone +49 (0) 7031 637 01
Fax +49 (0) 7031 637 740
<http://ecc.emea.honeywell.com>**AutomatikCentret**Strandvejen 42 ♦ Saksild ♦ 8300 Odder
86 62 63 64 ♦ www.automatikcentret.dk
info@automatikcentret.dk